


SymTech EGT Interface Module Installation Instructions:

Thank you for purchasing SymTech Labs' EGT Interface Module for use with MS/Extra-configured Megasquirt ECU's. Please be advised that this interface module is only compatible with K-type thermocouples.

Installation consists of connecting just five wires. Using the diagram below, locate each lead and connect to the following locations:

- **Switched +12V** - This lead must receive switched +12V (+/- 4V). To preserve battery life, it is best to remove all power from the EGT module while the vehicle is off.
- **Ground** - Connect this lead to a clean, reliable electrical ground. Chassis ground is often sufficient, but ensure that the wire contacts metal; remember that paint is an insulator. Nearby sources of noise (i.e. fuel injectors, spark coil) may cause adverse effects. If in doubt, the negative battery terminal will work well.
- **Output to Megasquirt** - This lead carries the conditioned EGT signal to the Megasquirt ECU. It must be connected to either pin JS4 on v3.0 boards, or X6 on v2.2 boards utilizing MS1/Extra.
- **Alumel (red)** - Connect this lead to the alumel lead of your K-type thermocouple. Alumel leads are often marked red.
- **Chromel (yellow)** - Connect this lead to the chromel lead of your K-type thermocouple. Chromel leads are often marked yellow.



WARNING

SymTech Laboratories assumes no responsibility for losses or damages due to installation of this product.

LIMITED WARRANTY

SymTech warrants to the original customer purchasing products directly from SymTech that all such products sold will be free from defects in materials and workmanship affecting form, fit and function. SymTech, at its option, will repair, replace, or provide a credit or refund of either the original purchase price or fair market value, whichever is lower, of any product that is determined by SymTech to be defective during the warranty period.

Any claim must be made within one (1) year from the original date of shipment by SymTech; SymTech shall have no liability thereafter. Customer must notify SymTech within one (1) year from the original date of shipment. The foregoing warranty granted on SymTech products is to the initial customer end-user and is non-transferable.

This warranty is in lieu of any and all other warranties, whether oral, written, expressed, implied or statutory. Implied warranties of fitness for a particular purpose and merchantability are specifically excluded and shall not apply. The above warranties cover only defects arising under normal use and do not include malfunctions or failures resulting from misuse, abuse, neglect, alteration, problems with electrical power, usage not in accordance with product instructions, acts of nature or improper installation or repairs made by anyone other than SymTech or a SymTech-authorized third party service provider. SymTech reserves the right to substitute functionally equivalent new or serviceable used parts.

COPYRIGHT NOTICE AND DISCLAIMER

This document and its content is copyright of "SymTech Laboratories" - © "SymTech Laboratories" 2006. All rights reserved.

Any redistribution or reproduction of part or all of the contents of this document in any form is prohibited.

You may not, except with our express written permission, distribute or commercially exploit the content. Nor may you transmit it or store it in any other website or other form of electronic retrieval system.